

Start of Program

Opening Diolan
Adapter

Initialize Device
Master SPI

Read parameter from
DISB Register

**Repeated for
different registers**

Write integration time
to DISB Register

**Repeated with two
different
integration times**

Trigger exposure via
write to Sensor CTRL
register

Read spectrum from
framebuffer

Closing Diolan
Adapter

